

SPOTLIGHT

INFUSIBLE INK CRICUT TOTE

N° 08.20.02
PROJECT SHEET



**SHOW US WHAT
YOU'RE MAKING**

 /spotlightstores

 @spotlightstores

INFUSIBLE INK CRICUT TOTE

e EASY

WHAT YOU'LL NEED

- Infusible Ink Paper of your choice, we are using Cricut Infusible Ink Transfer Sheet Patterns, Tropical Floral
- Computer
- Design Space apps
- Cricut EasyPress 2
- Cricut EasyPress Mat
- Cricut Explore Air 2 or Cricut Maker
- Cricut heat resistant tape
- Cricut tote bag blank
- StandardGrip Machine Mat - 12" x 12"
- Lint roller
- Butcher paper
- Tweezer
- Scissors
- Weeding tools
- Download png templates from Cricut Design Space app

INSTRUCTIONS

PREPARATION

Step 1 – If you subscribe to Cricut Design Space access, images is available to use.

- Image details 1: Geometric T-shirt Shapes/ T-shirt Design #M9A10A80
- Image details 2: Fell – Italy/Pizza Small #MD028910

Step 2 – Insert text “I DON’T NEED HOLIDAY I JUST NEED TO GO TO ITALY”.

Step 3 – Assemble images and text.

Step 4 – Use slice tools to cut text and pizza image on the main image.

CUT

Step 1 – Be sure to mirror the mat when using an Infusible Ink™ Transfer Sheet and place the shiny side (clear liner) down on the mat.

Step 2 – Follow the prompts in Design Space® to cut the images from the Infusible Ink™ Transfer Sheet.

Step 3 – Remove the unneeded pieces of vinyl using a Weeder Tool. It is usually easiest to move from the inside out when weeding.

ASSEMBLE

Step 1 – Follow below stacking order.

STACKING ORDER

- Cricut EasyPress 2
- Butcher paper
- Infusible Ink Transfer Sheet design, face down
- Cricut Tote Bag Blank

INSIDE CRICUT TOTE BAG

- White Cardstock (80 lb) or 4 layers butcher paper
- Cricut EasyPress Mat*

OTHER SUPPLIES

- Lint roller
- Tweezers

*Not recommended without Cricut EasyPress Mat

Step 2 - Preparation

- Preheat Cricut EasyPress 2 to 385°F
- Place mat inside tote bag
- Insert cardstock on top of mat inside tote bag to prevent bleed through
- Lint roll tote bag
- Cover tote bag with butcher paper larger than heat plate
- Preheat tote bag for 15 s
- Remove butcher paper from top of tote bag

Step 3 - Application

- Place design face down, liner side up
- Cover with clean butcher paper larger than heat plate
- Press with light pressure at 196°C for 40 s
- Slowly lift press
- Slowly remove butcher paper
- Slowly remove liner while warm

Note – If transfer sheet remains on shirt, remove with tweezers.

Step 4 - Care

- Machine wash inside out with cold water and mild detergent
- Tumble dry low or line dry
- Do not use fabric softener, dryer sheets, or bleach

*Images for this project available to download from Design Space, fee may be applied