

KIDS DECORATOR TEEPEE



e EASY


WHAT YOU'LL NEED

- Approx. 4m Cotton Canvas Fabric
- Cord. 4 Pieces Approx. 30cm
- Approx. 180-200m Dowel Rods X 4
- Sewing Machine


INSTRUCTIONS

- Step 1- Measure and cut fabric 4 triangle pieces, 1 Base Piece and 4 rectangle pieces as per pattern. Pay attention to the direction of prints.
- Step 2- Fold the 4 rectangle pieces in half wrong side out, sew long side shut, turn out. These are the pole pockets. Sandwich between long edge of triangle pieces.
- Step 3- Cut Front panel, leave 40cm at top of panel. Fold 1cm seam and stitch to create door opening. You may wish to sew binding on this door opening. Attach ties to front panel opening (refer to photo)
- Step 4- Stitch on 4 pieces of cording at top of front panel.
- Note: This will assist in securing the poles to the top of the teepee
- Step 5- Sew all triangle pieces together on long edges.
- Step 6- Stitch 3 of the Triangle pieces to the Base piece, excluding Front Panel. (As the front panel is the opening)
- Step 7- Insert Dowel Rods and tie together with cord at the top.









SPOTUCHT