

FESTIVE FACE MASK



e EASY

WHAT YOU'LL NEED

- 30cm Jocelyn Proust Christmas Fabric
- 30cm Light Weight Fusible interfacing
- 2 x 18cm pieces of elastic
- Sewing machine and matching thread
- Scissors
- Pins
- Iron and Ironing Board

INSTRUCTIONS

- Step 1 Trace around template onto fabric and fusing. You should have 6 pieces in total, 4 from fabric and 2 from interfacing.
- Step 2 Use an iron to fuse the interfacing onto the wrong side of 2 of the fabric pieces. Ensure the shiny side of fusing is facing the wrong side of the fabric as this is what will fuse them together.
- Step 3 Place the fabric pieces right sides facing in and pin in place. Sew together with a 1cm seam allowance along the curved edge.
- Step 4 Snip into the curved seam and then press the seam allowance to one side and top stitch in place. Repeat on other side.
- Step 5 Fold the pleats on each end of the mask, matching the notches and pining in place.
- Step 6 Stitch 5mm in from the ends of the mask and over the pleats to secure.
- Step 7 Place mask pieces together with right sides facing in. Sew along top and bottom edges with a 1cm seam allowance.
- Step 8 Turn mask right side out. Then carefully fold in roughly 1cm at both ends and pin in place.
- Step 9 Cut 2 pieces of elastic 18cm long and position into the seams at both ends of the mask.

Step 10 - Top stitch around the entire mask securing the elastic at both ends to finish! Your festive mask is now complete.





