

SPOTLIGHT

INFUSIBLE INK CRICUT COASTER

Nº 08.20.03
PROJECT SHEET



**SHOW US WHAT
YOU'RE MAKING**

 /spotlightstores

 @spotlightstores

INFUSIBLE INK CRICUT COASTER

e EASY

WHAT YOU'LL NEED

- Materials to Cut – Infusible Ink Paper of your choice, we are using Cricut Infusible Ink Transfer Sheet Patterns, Watercolor Splash
- Computer
- Design Space apps
- Cricut EasyPress 2
- Cricut EasyPress Mat
- Cricut Explore Air 2 or Cricut Maker
- Cricut heat resistant tape
- Cricut ceramic coaster
- StandardGrip Machine Mat - 12" x 12"
- Lint roller
- Butcher paper
- Tweezer
- Scissors
- Weeding tools
- Download png templates from Cricut Design Space app

INSTRUCTIONS

PREPARATION CONSTELLATION COASTER

Step 1 – If you are subscribed to the Cricut Design Space access, constellation project or images is available to use.

- Image details 1: Summer Love/Big Dipper #M19CD5A
- Image details 2: Summer Love/Orion #M18EAFD

Step 2 – Insert two CIRCLES size 8.25cm.

Step 3 – Insert both images.

Step 4 – Assemble images.

Step 5 – Use slice tools to cut image on the circle.

Step 6 – Delete sliced images that you are not going to use.

PREPARATION EIFFEL TOWER COASTER

Step 1 – If you subscribed to Cricut Design Space access, image is available to use.

Image detail 3: Destinations/Paris Eiffel Tower #M83D8FEB

Step 2 – If you do not have Design Space access. Upload image 3 to Design Space.

Step 3 – Insert two CIRCLES size 8.25cm.

Step 4 – Insert both images.

Step 5 – Assemble images.

Step 6 – Use slice tools to cut image on the circle.

Step 7 – Delete sliced images that you are not going to use.

CUT

Step 1 – Be sure to mirror the mat when using an Infusible Ink™ Transfer Sheet and place the shiny side (clear liner) down on the mat.

Step 2 – Follow the prompts in Design Space® to cut the images from the Infusible Ink™ Transfer Sheet.

Step 3 – Remove the unneeded pieces of vinyl using a Weeder Tool. It is usually easiest to move from the inside out when weeding.

ASSEMBLE

Step 1 – Follow below stacking order.

STACKING ORDER

- Cricut EasyPress 2
- Butcher paper
- Cricut Ceramic Coaster Blank
- Infusible Ink Transfer Sheet design
- White Cardstock (80 lb) or 4 layers butcher paper
- Cricut EasyPress Mat*

OTHER SUPPLIES

- Lint-free cloth

*Not recommended without Cricut EasyPress Mat

Step 2 – PREPARATION

- Preheat Cricut EasyPress 2 to 200°C
- Wipe tile with lint-free cloth
- Cover mat with cardstock to protect surface
- Preheat tote bag for 15 s
- Remove butcher paper from top of tote bag

Step 3 – APPLICATION

- Position design on coaster
- Place coaster with design face down on cardstock
- Cover with clean butcher paper
- Center machine, press with no pressure at 200°C for 240 s without moving press
- Lift press
- Remove butcher paper

CAUTION – Coaster will be very hot. Let cool completely. Remove coaster from design.

Step 4 – CARE

Wash with warm water and glass cleaner.

Do not use steel wool, colored cleansing agents, or scrubbing pads.

*Images for this project available to download from Design Space, fee may be applied