

SPOTLIGHT

**INFUSIBLE
INK
COMPASS
TOTE**

N° 09.20.08
PROJECT SHEET



**SHOW US WHAT
YOU'RE MAKING**

 /spotlightstores

 @spotlightstores

INFUSIBLE INK COMPASS TOTE

e EASY

WHAT YOU'LL NEED

- Materials to Cut – Infusible Ink Paper of your choice, we are using Cricut Infusible Ink Transfer Sheet Patterns, Rainbow
- Computer
- Design Space Apps and access
- Cricut EasyPress 2
- Cricut EasyPress Mat
- Cricut Explore Air 2 or Cricut Maker
- Cricut heat resistant tape
- Cricut tote bag blank
- StandardGrip Machine Mat – 12" x 12"
- Lint roller
- Butcher paper
- Tweezer
- Scissors
- Weeding tools

INSTRUCTIONS

PREPARATION

Step 1 – If you subscribe to Cricut Design Space access, search floral compass project.

Step 2 – If you want to alter the project, select Customize, then use the tools in the Edit panel to make changes before you cut.

CUT

Step 1 – Be sure to Mirror the mat when using an Infusible Ink Transfer Sheet and place the shiny side (clear liner) down on the mat.

Step 2 – Follow the prompts in Design Space® to cut the images from the Infusible Ink™ Transfer Sheet.

ASSEMBLE

Step 1 – Follow the listed stacking order.

Stacking Order:

- Cricut EasyPress 2
- Butcher paper
- Infusible Ink Transfer Sheet design, face down
- Cricut Tote Bag Blank

Inside Cricut Tote Bag:

- White cardstock (80 lb) or 4 layers butcher paper
- Cricut EasyPress Mat*

Other Supplies:

- Lint roller
- Tweezers
- * Not recommended without Cricut EasyPress Mat.

Step 2 – PREPARATION

- Preheat Cricut EasyPress 2 to 195°C
- Place mat inside tote bag
- Insert cardstock on top of mat inside tote bag to prevent bleed through
- Lint roll tote bag
- Cover tote bag with butcher paper larger than heat plate
- Preheat tote bag for 15 s
- Remove butcher paper from top of tote bag

Step 3 – APPLICATION

- Place design face down, liner side up
- Cover with clean butcher paper larger than heat plate
- Press with light pressure at 195°C for 40 s
- Slowly lift press
- Slowly remove butcher paper
- Slowly remove liner while warm

Note: If transfer sheet remains on shirt, remove with tweezers.

Step 4 – CARE

- Machine wash inside out with cold water and mild detergent
- Tumble dry low or line dry
- Do not use fabric softener, dryer sheets, or bleach